


# **DEFAULT BARCODE CARD**

For Module and Fixed Mount Scanners:



Scan this programming code to restore scanner parameters to factory default settings.

Remark: The default settings are associated to configuration in Chapter 3 to Chapter 8.



V1.1 2015 Dec